

Installation and Operation Instructions for No. 08655-0007 and 08655-0017 Check Valves.





Figure 1: Check valve installation. Tighten finger-tight only.




Figure 2: Normal skimmer operation;
check valve shut, water flows
through skimmer.




Figure 3: Equalizer operation: Float
valve shut, check valve open, water
flows through equalizer line to avoid
starving the pump.




Figure 4: To vacuum pool, remove
check valve and plug port; reinstall
check valve after vacuuming.

Sta-Rite Pool/Spa Group

293 Wright Street, Delavan, WI 53115

International: 262-728-5551, FAX: 262-728-7550

www.starite.com

Union City, TN • Delavan, WI • Mississauga, ON • Murrieta, CA