


# Control Parts

## All Button Indoor Controller Parts Diagram and List



Dwg#	Part #	Description
1	6893	Controller Housing with decals, Front RS 8 Combo
1	6894	Controller Housing with decals, Front RS 8 Only
1	6895	Controller Housing with decals, Front RS 6 Combo
1	6896	Controller Housing with decals, Front RS 6 Only
1	6897	Controller Housing with decals, Front RS 4 Combo
1	6898	Controller Housing with decals, Front RS 4 Only
1	6899	Controller Housing with decals, Front RS 2/6 Dual Equipment
1	7350	Indoor Control Panel, RS 2/10 Dual Equipment
1	7434	Controller Housing with decals, Front RS 16 Combo
1	7436	Controller Housing with decals, Front RS 12 Combo
1	7438	Controller Housing with decals, Front RS 2/10 Dual Equipment
2	6546	Key Pad, AquaLink RS Controller
3	6475	P.C.B., AquaLink RS Controller Use Part #6475LED4
4	6803	L.C.D. Display - w/cable
5	6544	Controller Housing, Back
6	6847	Screw Kit, PCB Mounting
7	6609	Terminal Bar, 4 Pin, Red
8	6912	Screw Kit, Controller Mount (Not Available Separately) use Kit #6578
n/s	6578	Controller Mounting Kit (incl. Aux. Decals, Battery, Mounting Screws)
n/s	6781	Decals, Auxiliary Equipment Labels
n/s	7057	Service Controller, All Button w/10 ft. cable & connector