

SWIMLINE®

RC SUBMARINE

For Ages 8 and Up


Transmitter Uses:

1-9V size battery (not included)

Submarine Uses:

4 "AA" size batteries (not included)

**FOR AWESOME,
REALISTIC SUBMARINE
ACTION!**



Thank you for purchasing the Swimline RC Submarine. Your Submarine can dive below the water for depths to 4 feet and has full directional steering functions. It can reach speeds of up to 50 feet per minute.

THIS PRODUCT IS DESIGNED FOR POOLS AND PONDS. DO NOT USE THE SUBMARINE IN SALT WATER.

CAUTION: For safety, children playing with this toy should be supervised by an ADULT, as with any products designed to be used in or around water. To maintain good sub performance and control, make sure that your RC Submarine is operated at depths that do not exceed 4 feet.

INSTALLING BATTERIES

Note: Any batteries purchased for use in this toy may pose a hazard to children, please check safety notice supplied with batteries before use.

Warning: Dispose of batteries promptly and properly; do not bury or burn them.

Cautions:

- Batteries to be installed by adults only.
- Use only fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.
- After each use of the Submarine, remove all batteries from the product, and drain any water that has accumulated inside. Moisture allowed to remain inside the product will damage the electronic components and batteries. Store the product with the battery compartment door open to allow the compartment to dry completely.

Your Submarine needs the batteries listed below for power, for best performance and longest life.

- One 9V battery for the transmitter.
- Four AA batteries for the Submarine.

In The Transmitter

- Use a Phillips screwdriver to loosen the screw on the battery compartment cover and lift the

- cover to remove it.
- Put one 9V battery in the compartment as indicated by the polarity symbols (+ and -) marked inside.
- Replace the battery cover and secure it with the screw.

Note : When the transmitter's range decreases, replace its battery.


In the Submarine

- Press button on back of submarine and turn the tail of submarine counterclockwise until it



stops, then pull out the tail.

- Take out the battery compartment box from the compartment as shown.
- Install four AA batteries in the battery compartment box according to the polarity symbols (+ and -) marked inside.
- Replace battery compartment box in compartment. The box fits only in one way. If it does not go, pull out, turn upside down and reinsert. Do not force it.
- Put tail back on submarine body and turn it clockwise to lock it.

Note: If the Submarine runs slowly or not at all or does not respond to the transmitter, replace the AA batteries.



WARNING:
CHOKING HAZARD-Small parts
Not for children under 3 years



WARNING:

Only to be used in water in which the child is within its depth and under supervision.

Imported for:

ILP/Swimline

191 Rodeo Drive

Edgewood, NY 11717

www.swimline.com

Made In China

BALANCING THE SUBMARINE

Unequal weight distribution of your submarine affects the balancing in the water and impairs submarine operation. To avoid this, there is weight compartment on the bottom of the submarine. Turn the latch to OPEN direction and open the compartment cover. Insert the weights supplied to any of the 6 slots so the submarine is balanced LEVEL in the water. Replace the cover and turn the latch to CLOSE to lock the compartment cover.


First try floating the submarine. You can try this in the kitchen basin or bathtub: no need to go to pond lake or swimming pool.

If the submarine slants, add weights to the opposite

side of slant. If the submarine floats high and the propellers do not sink below the water, add weights evenly to each compartment.

The best balanced position is when the water level covers the submarine's body, leaving only the top of the telescope visible above the water.

Note: Be careful when you insert or take out weights. You can use a pointed object to remove the weights. Keep the weight compartment facing up to prevent the weights you just inserted from falling out.




DRIVING THE SUBMARINE

Note: Keep the two propellers in the same position before you put the submarine in water in order to keep the submarine in balance.

1. Press ON/OFF button on the transmitter to ON. The LED near the telescope and the headlight both light.
3. Use the transmitter's control buttons to control the Submarine.
4. When finished using your RC Submarine,

Remove all batteries from the Submarine and transmitter. Then turn over the submarine and empty any water from the hull. Dry the Submarine thoroughly before you store it. Leave the Submarine's battery compartment cover open while it is in storage to allow moisture to evaporate.

Note: The submarine moves forward once both the transmitter and the submarine are turned ON. Never touch or put your fingers near the propellers while they are spinning.



HELPFUL HINTS

- Running your Submarine continuously for long periods generates high heat levels. Heat causes wear and tear on the Submarine. To help keep heat levels down, when your Submarine's battery die, let the Submarine cool at least 10 minutes before installing fresh batteries.
- If the Submarine's motor runs but does not respond to the transmitter, move closer to the Submarine and try again.
- If some one uses a CB nearby, it might interfere with control of the Submarine. If this happens, move the Submarine away from the CB.
- You cannot operate your Submarine near devices with transmitters that use the same frequency as your Submarine (27MHz or 49MHz). Check the box to see which frequency you have.
- If the Submarine moves slowly, and you have installed fresh batteries, check the runner mechanisms for lint, thread, hair, or dust.

CARE AND MAINTENANCE

Do not use the submarine in strong currents, in salt water, or in any body of water with large waves. Never touch or put your fingers near the propellers while they are spinning.

Never play with the submarine in strong winds. Never play with the submarine outside in thunder storms. Do not let the submarine submerge more than 3 feet depth. You might lose the control.

Be careful not to wade into deep water or strong currents. When the submarine goes outside the transmitter's control range, hold the transmitter as high as possible with the antenna vertical to re-establish contact. If you cannot, move closer to the submarine to control it.

Always turn on the transmitter first, then the submarine, and turn off the submarine first then the transmitter. Otherwise, your submarine might pick up other radio waves and start moving while the transmitter is off. Should this happen, immediately turn on the transmitter on to bring the submarine under your control.

Do not let the submarine run aground. Keep it away from grass growing in the water and other debris that could cause propeller damage. These items can jam the propellers and stop the submarine away from the shore.

When the batteries begin to lose power, the

submarine slows down. To be sure the submarine can make it to shore, guide it in as soon as you notice it slowing down.

Do not leave your submarine in the water when you finish playing. Water might seep into the hull and damage electronic parts.

CARE

Never play with your submarine in salt water: doing so might rust its parts. Use and store the submarine only in a normal temperature environment. Handle the submarine gently and carefully; do not drop it. Keep the submarine away from dust and dirt. Wipe the submarine clean with a dry towel after playing. Do not use chemicals on the submarine as they can damage the body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is advised to take one or more of the following steps: reorient or relocate the receiving antenna; increase the distance between the equipment and the receiver; turn on the equipment and see if the interference goes away. If the interference persists, contact the user's local government or FCC.